

TransIT-VirusGEN® SELECT Transfection Reagent



Protocol for MIR 6730 and MIR 6735

Quick Reference Protocol, SDS and Certificate of Analysis available at mirusbio.com/6730

INTRODUCTION

Efficient, high titer and large-scale viral vector manufacturing processes are necessary for production of viral vectors such as lentivirus and adeno-associated virus (AAV) for gene- and cell-based therapies. Additionally, raw or ancillary materials used for viral vector manufacturing must be carefully selected as part of a risk-based approach for the development of therapeutics. The *TransIT-VirusGEN®* SELECT Transfection Reagent addresses both needs by providing robust titers for lentivirus and AAV production and comprehensive quality documentation for researchers developing biotherapeutics for immunotherapy.

TransIT-VirusGEN® SELECT is identical in formulation to the *TransIT-VirusGEN®* Transfection Reagent, which was developed by screening lipid and polymer libraries to identify a reagent formulation that enhances delivery of virus packaging and transfer vectors to HEK 293 cells. Using a functional titer read-out, Mirus scientists identified this novel transfection formulation that enables high titer lentivirus and AAV production in both adherent, serum-containing cultures, as well as serum-free suspension 293-derived cell types. The streamlined virus generation workflows and culture format versatility make *TransIT-VirusGEN®* an ideal reagent for scientists utilizing a variety of virus platforms. With *TransIT-VirusGEN®* SELECT, researchers can expect the same reliable, scalable and flexible performance of the *TransIT-VirusGEN®* Transfection Reagent as they progress from discovery and development to pre-clinical trials.

In addition to the Quality Control testing established for *TransIT-VirusGEN®* Transfection Reagent, the *TransIT-VirusGEN®* SELECT Transfection Reagent is further qualified with appearance, sterility, identity, mycoplasma and endotoxin assays.

SPECIFICATIONS

Storage	Store <i>TransIT-VirusGEN®</i> SELECT Reagent at -10 to -30°C, tightly capped. <i>Before each use</i> , warm to room temperature and vortex gently.
Stability / Guarantee	Guaranteed as noted on the Certificate of Analysis when properly stored and handled.



Warm *TransIT-VirusGEN®* SELECT Reagent to room temperature and vortex gently before each use.

MATERIALS

Materials Supplied

TransIT-VirusGEN® SELECT Transfection Reagent is supplied in the following formats.

Product No.	Quantity
MIR 6730	1 × 30 ml
MIR 6735	1 × 150 ml

For Materials Required but Not Supplied, see Protocol Sections:

- (I) Lentivirus Generation in Adherent HEK 293T Cell Cultures
- (II) Lentivirus Generation in Suspension HEK 293 Cell Cultures
- (III) Lentivirus Transduction and Titering Protocol Using GFP Reporter Virus
- (IV) AAV Generation in Adherent 293T Cell Cultures
- (V) AAV Generation in Suspension 293 Cell Cultures
- (VI) AAV Transduction/Titering Method Using a GFP Reporter Virus

For Research Use Only

BEFORE YOU START:

Important Tips for Optimal Lentivirus or AAV Production

Mirus recommends using HEK 293T/17 cells (ATCC Cat. No. CRL-11268) or Expi293F™ Cells (Gibco Cat. No. A14527) for high titer AAV or lentivirus production in adherent or suspension HEK 293 cultures, respectively. The suggestions below yield high efficiency plasmid DNA transfection using the *TransIT-VirusGEN®* SELECT Transfection Reagent.

- **Cell density (% confluence) at transfection.** The recommended cell density for adherent HEK 293T/17 cells is 80-95% confluence at the time of transfection. The recommended cell density for suspension Expi293F™ cells is 2×10^6 cells/ml. Passage cells 18-24 hours before transfection to ensure that cells are actively dividing and reach the appropriate density at time of transfection.
- **DNA purity.** Use highly purified, sterile, endotoxin-free and contaminant-free DNA for transfection. Plasmid DNA preparations that have an $A_{260/280}$ absorbance ratio of 1.8-2.0 are desirable. DNA prepared using miniprep kits is not recommended as it might contain high levels of endotoxin. We recommend using MiraCLEAN® Endotoxin Removal Kit (MIR 5900) to remove endotoxin from your DNA preparation.
- **Lentivirus packaging and transfer plasmids.** The *TransIT-VirusGEN®* SELECT Reagent was optimized using a lentivirus packaging vector pre-mix. If using individual packaging plasmids, we recommend a starting ratio of 4 µg *gag-pol* vector, 1 µg *rev* vector and 1 µg VSV-G vector. Premix the packaging plasmids with an equal amount of the transfer vector (e.g. 6 µg) to maintain a 1:1 (wt:wt) ratio of packaging to transfer plasmids.
- **AAV packaging and transfer plasmids.** The *TransIT-VirusGEN®* SELECT Reagent was optimized using a 1:1:1 weight ratio of pAAV-hrGFP, pAAV-RC and pHelper (AAV Helper-Free System, Agilent Technologies).
- **Ratio of *TransIT-VirusGEN®* SELECT to DNA.** Determine the optimal *TransIT-VirusGEN®* SELECT Reagent:DNA ratio for each cell type by varying the amount of reagent from 2-4 µl (lentivirus) or 1-3 µl (AAV) per 1 µg total DNA. Refer to **Tables 1-4** in the Lentivirus and AAV sections for recommended starting conditions based on cell culture vessel size.
- **Complex formation conditions.** Prepare *TransIT-VirusGEN®* SELECT Reagent:DNA complexes in Dulbecco's Phosphate Buffered Saline (DPBS) without calcium or magnesium (Millipore Sigma Cat. No. D8537). Alternatively, a serum-free growth medium such as Opti-MEM® I Reduced-Serum Medium (Gibco Cat. No. 31985-070) can also be used.
- **Cell culture conditions.** Culture cells in the appropriate medium, with or without serum (e.g. DMEM + 10% FBS + 10 mM HEPES pH 7.4 for adherent 293T cultures; Expi293™ Expression Medium for suspension 293 cultures). After transfection, there is no need to perform a medium change to remove the transfection complexes.
- **Presence of antibiotics.** Antibiotics inhibit transfection complex formation and should be excluded from the complex formation step. Transfection complexes can be added directly to cells growing in complete culture medium containing serum and low levels of antibiotics (0.1-1X final concentration of penicillin/streptomycin mixture).
- **Media change post-transfection.** A media change is not required and could be detrimental to virus titers; therefore, we do not recommend a media change post-transfection.
- **Post-transfection incubation time for lentivirus.** The optimal incubation time for harvesting high titer lentivirus is 48 hours. Minimal amounts of functional lentivirus are produced during the period of 48-72 hours post-transfection.
- **Post-transfection incubation time for AAV.** The optimal incubation time for harvesting high titer AAV is generally 48-72 hours post-transfection.



Premix packaging and transfer plasmids together prior to adding to the complex formation medium.



Do not use serum or antibiotics in the media during transfection complex formation.

Transfection complexes can be added directly to cells cultured in growth media +/- serum and up to 0.1-1X antibiotics.

SECTION I: Lentivirus Generation in Adherent HEK 293T Cell Cultures

The following procedure describes plasmid DNA transfections for lentivirus generation in adherent HEK 293T cell types in a 6-well plate format. The surface areas of other culture vessels are different, and transfections must be scaled accordingly. Appropriately increase or decrease the amounts of serum-free medium, *TransIT-VirusGEN® SELECT* Reagent, total plasmid DNA and complete culture medium based on the size of the cell culture vessel (refer to **Table 1** below).

Table 1. Recommended *TransIT-VirusGEN® SELECT* starting conditions for LV production

Culture vessel	6-well plate	10-cm dish	T75 flask	T175 flask	Corning® 2-STACK	Corning® 5-STACK
Surface area	9.6 cm ²	59 cm ²	75 cm ²	175 cm ²	1272 cm ²	3180 cm ²
Complete growth medium	2.0 ml	10 ml	15 ml	35 ml	260 ml	650 ml
PBS or Serum-free medium	200 µl	1.0 ml	1.5 ml	3.5 ml	26 ml	65 ml
Transfer DNA (1 µg/µl stock)	1.0 µl	5 µl	7.5 µl	17.5 µl	130 µl	325 µl
Packaging DNA Premix (1 µg/µl stock)	1.0 µl	5 µl	7.5 µl	17.5 µl	130 µl	325 µl
<i>TransIT-VirusGEN® SELECT</i> Reagent	6 µl	30 µl	45 µl	105 µl	780 µl	1.95 ml



Surface areas are based on Falcon plates, dishes and flasks, and Corning CellSTACK® Culture Chambers. Volumes are per well (or dish) for a given culture vessel. For vessels not listed in this table, volumes of PBS, total DNA and *TransIT-VirusGEN® SELECT* Reagent can typically be scaled according to surface area (cm²).

Materials Required but Not Supplied

- HEK 293T cells (e.g. HEK 293T/17 cells, ATCC Cat. No. CRL-11268)
- Complete culture medium (e.g. DMEM + 10% FBS + 10 mM HEPES pH 7.4)
- Nucleic acid (packaging plasmids and transfer vector with gene of interest)
- Phosphate Buffered Saline (PBS) (e.g. Millipore Sigma Cat. No. D8537)
- 0.45 µm PVDF filter (e.g. Millipore Cat. No. SE1M003M00 or SLHV033RS)
- Reporter assay as required




Divide cultured cells 18-24 hours before transfection to ensure active cell division at the time of transfection.

Transient Plasmid Transfection Protocol per Well of a 6-Well Plate

A. Plate cells

1. Approximately 18-24 hours before transfection, plate cells in 2.0 ml complete growth medium per well in a 6-well plate. A starting cell density of 4.0 - 5.0 × 10⁵ cells/ml is recommended. Cultures should be 80-95% confluent at the time of transfection (see representative image at right).
2. Incubate cell cultures at 37°C in 5% CO₂ overnight.

Representative image of ~80% confluent 293T/17 cells:



B. Prepare *TransIT-VirusGEN®:DNA* complexes (immediately before transfection)

1. Warm *TransIT-VirusGEN® SELECT* Transfection Reagent to room temperature and vortex gently before using.
2. Place 200 µl PBS in a sterile tube.
3. In a separate sterile tube, combine the packaging plasmid premix (or individual plasmids) and transfer plasmid encoding the gene of interest (GOI). Mix thoroughly.
4. Transfer 2.0 µg (1 µg packaging plasmid mix + 1 µg transfer plasmid) of the DNA prepared in Step B.3 to the tube containing PBS. Mix completely.
5. Add 6.0 µl *TransIT-VirusGEN® SELECT* Reagent to the diluted DNA mixture. Mix completely by inversion or vortexing. Do NOT agitate Reagent:DNA complexes again after this initial mixing.



Do NOT allow the *TransIT-VirusGEN® SELECT* Reagent to incubate alone in complex formation solution > 5 min, i.e. if the reagent is pre-diluted, add DNA within 5 min for optimal complex formation.

Do NOT agitate Reagent:DNA complexes after the initial mixing.

NOTE: This is a 3:1 mixture of transfection reagent to total DNA (vol:wt), which can be further optimized for lentivirus production using *TransIT-VirusGEN® SELECT* Reagent.

- Incubate at room temperature for 15-60 minutes to allow transfection complexes to form.

C. Distribute the complexes to cells in complete growth medium

- Add the *TransIT-VirusGEN® SELECT* Reagent:DNA complexes (prepared in Step B) drop-wise to different areas of the wells.
- Gently rock the culture vessel back-and-forth and from side-to-side to evenly distribute the *TransIT-VirusGEN® SELECT* Reagent:DNA complexes.
- Incubate at 37°C in 5% CO₂ for 48 hours.

NOTE: It is not necessary to replace the complete growth medium with fresh medium post-transfection.

D. Harvest and storage of lentivirus

- Harvest cell supernatant containing recombinant lentivirus particles.
NOTE: If cells detach during harvest, centrifuge cells at 300 × g for 5 minutes and retain the virus-containing supernatant.
- Filter virus-containing supernatant through a 0.45 µm PVDF filter to remove any cells.
- Immediately flash freeze aliquots of lentivirus in cryogenic tubes and store at -80°C.



There is no need to change culture medium after transfection.

Transfection complexes, visualized as small particles, are sometimes observed following transfection. The complexes are not toxic to cells and do not affect transfection efficiency or transgene expression.

SECTION II: Lentivirus Generation in Suspension HEK 293 Cell Cultures

The following procedure describes plasmid DNA transfections for lentivirus generation in 125 ml Erlenmeyer shake flasks using 25 ml of complete growth medium. If using alternate cell culture vessels, increase or decrease the amounts of serum-free complex medium, *TransIT-VirusGEN® SELECT* Reagent and total DNA based on the **volume of complete growth medium** to be used. To calculate the required reagent quantities based on the recommended starting conditions and total culture volume, refer to the calculation worksheet in **Table 2** (below).

Table 2. Scaling worksheet for *TransIT-VirusGEN® SELECT* Reagent for LV transfections

Starting conditions per milliliter of complete growth medium (Lentivirus Generation)				
	Per 1 ml		Total culture volume	Reagent quantities
PBS or serum-free medium	0.1 ml	×	_____ ml	= _____ ml
Transfer plasmid DNA (1 µg/µl stock)	0.5 µl	×	_____ ml	= _____ µl
Packaging DNA premix (1 µg/µl stock)	0.5 µl	×	_____ ml	= _____ µl
<i>TransIT-VirusGEN® SELECT</i> Reagent	3 µl	×	_____ ml	= _____ µl



TransIT-VirusGEN® SELECT Reagent was optimized using a pre-mix of lentivirus packaging vectors. If using individual packaging plasmids, we recommend a starting ratio of 4 µg gag-pol vector, 1 µg rev vector and 1 µg VSV-G vector. Premix the packaging plasmids with an equal amount of the transfer vector (e.g. 6 µg) to maintain a 1:1 (wt:wt) ratio of packaging to transfer plasmids.

Materials Required but Not Supplied

- Suspension HEK 293 cells (e.g. Expi293F™, Gibco Cat. No. A14527)
- Complete Culture Medium (e.g. Expi293™ Expression Medium, Gibco Cat. No. A1435101)
- Nucleic acid (2nd or 3rd generation packaging plasmids and transfer vector with GOI)
- Phosphate Buffered Saline (PBS) (e.g. Millipore Sigma Cat. No. D8537)
- Erlenmeyer shake flasks (e.g. Corning® Cat. No. 431143 or Thomson Cat. No. 931110)
- 50 ml conical tube(s) for virus collection
- 0.45 µm PVDF filter (e.g. Millipore Cat. No. SE1M003M00 or SLHV033RS)
- Reporter assay as required

Transient Plasmid Transfection Protocol per 25 ml HEK 293 Culture

A. Maintenance of cells

1. Passage suspension HEK 293 cells 18-24 hours prior to transfection to ensure that cells are actively dividing at the time of transfection and to obtain a density of $2 - 3 \times 10^6$ cells/ml the next day.

NOTE: Perform cell counts and evaluate viability daily to ensure that cells are doubling every 24 hours and $\geq 95\%$ viable by trypan blue exclusion. DO NOT proceed with transfection if cells are not doubling normally or are $< 95\%$ viable.

2. Incubate cells overnight at appropriate temperature and CO₂ levels (e.g. 37°C, 5-8% CO₂, shaking).

B. Prepare TransIT-VirusGEN®:DNA complexes (immediately before transfection)

1. Immediately prior to transfection, seed cells at a density of 2×10^6 cells/ml into a transfection culture vessel (e.g. 25 ml per 125 ml Erlenmeyer shake flask).
2. Warm TransIT-VirusGEN® SELECT Reagent to room temperature and vortex gently.
3. Place 2.5 ml of PBS in a sterile tube.
4. In a separate sterile tube, combine the packaging plasmid premix (or individual plasmids) and transfer plasmid encoding the gene of interest (GOI). Mix thoroughly.
5. Add 25 µg total plasmid DNA (i.e. combined transfer and packaging plasmids prepared in step B4) to the tube containing PBS. Mix completely.
6. Add 75 µl TransIT-VirusGEN® SELECT Reagent to the diluted DNA. Mix completely by inversion or vortexing. Do NOT agitate Reagent:DNA complexes again after this initial mixing.

NOTE: This is a 3:1 mixture of transfection reagent to total DNA (vol:wt), which can be further optimized for lentivirus production using TransIT-VirusGEN® SELECT Reagent.

7. Incubate at room temperature for 15-60 minutes to allow transfection complexes to form.

C. Distribute the complexes to cells in complete growth medium

1. Add the TransIT-VirusGEN® SELECT Reagent:DNA complexes (prepared in Step B) to the flask containing cells.
2. Shake flasks on an orbital shaker (125 rpm when using a shaker with a 1.9 cm orbital throw) at appropriate temperature and CO₂ levels (e.g. 37°C, 5-8% CO₂).
3. Incubate cultures for 48 hours prior to lentivirus harvest.

D. Harvest and storage of lentivirus

1. Following the 48-hour incubation, centrifuge the lentivirus containing culture(s) in sterile conical tube(s) at $300 \times g$ for 5 minutes. DO NOT dispose of supernatant following centrifugation.
2. Collect the virus-containing supernatant using a serological pipet into a sterile conical tube.
NOTE: If a large batch of the same virus is produced, the supernatants can be combined.
3. Filter the virus-containing supernatant through a 0.45 µm PVDF filter (e.g. Millipore Steriflip-HV, Cat. No. SE1M003M00) to remove any cells.
4. Immediately flash-freeze aliquots of lentivirus in cryogenic tubes and store at -80°C.



Divide cultured cells 18-24 hours before transfection to ensure that cells are actively dividing at the time of transfection.



Do NOT allow the TransIT-VirusGEN® SELECT Reagent to incubate alone in complex formation solution > 5 min, i.e. if the reagent is pre-diluted, add DNA within 5 min for optimal complex formation.

Do NOT agitate Reagent:DNA complexes after the initial mixing.



There is no need to change culture medium after transfection, unless required by your cell type or culture conditions.

SECTION III: Lentivirus Transduction and Titering Protocol Using GFP Reporter Virus

The following procedure describes transduction of HEK 293T/17 cells grown in a 24-well format with a GFP reporter lentivirus to determine functional lentivirus titers. The number of wells needed for this assay will depend on the number of lentivirus stocks titered and the number of dilutions required for testing per stock (see Step B.5). Testing several dilutions is recommended to accurately determine the functional lentivirus titer.

Materials Required, but Not Supplied

- HEK 293T/17 cells (ATCC Cat. No. CRL-11268)
- Appropriate cell culture medium (e.g. DMEM + 10% FBS + 10 mM HEPES pH 7.4)
- Lentivirus stock(s) expressing GFP reporter
- *TransduceIT*TM Reagent (10 mg/ml, Mirus Cat. No. MIR 6620) or hexadimethrine bromide (Sigma Cat. No. H9268)
- 24-well tissue culture plate(s)
- 1X PBS and trypsin
- Flow cytometer equipped with a GFP compatible laser

A. Plate cells

1. Approximately 18-24 hours before transduction, plate HEK 293T/17 cells in 0.5 ml complete growth medium per well in a 24-well plate. A starting cell density of 2.0×10^5 cells/ml is recommended. Cultures should be $\geq 40\%$ confluent at the time of transduction (see image at right).

NOTE: Plate at least two extra wells to trypsinize and count on the day of transduction. An accurate cell count at the time of transduction is critical to determine an accurate functional titer (see B.1).

2. Incubate cell cultures at 37°C in 5% CO₂ overnight.

B. Transduce with GFP-encoding recombinant lentivirus


1. Trypsinize and count 2 wells of untransduced cells (plated in A.1) to obtain an accurate cell concentration at the time of transduction.
2. Dilute *TransduceIT*TM Reagent or hexadimethrine bromide to a working concentration of 16 µg/ml in pre-warmed complete growth medium (e.g. add 16 µl of a 10 mg/ml solution into 10 ml of growth medium).
3. Gently remove half of the medium from each well using a P1000 micropipettor.
4. Immediately add 250 µl of the *TransduceIT*TM or hexadimethrine bromide working solution to each well. The final concentration should be 8 µg/ml per well. NOTE: If transducing cell types other than HEK 293T/17, the optimal concentration of *TransduceIT*TM or hexadimethrine bromide should be empirically determined.
5. Add dilutions of the lentivirus stock to separate wells. Testing several dilutions is recommended to accurately determine functional titer. Guidelines are as follows:
 - For titers expected to be $< 5.0 \times 10^7$ TU/ml, add 1 µl, 3 µl and 5 µl of the lentiviral stock to separate wells.
 - For titers expected to be $\geq 5.0 \times 10^7$ TU/ml, dilute the virus stock 10-fold in complete growth media. Add 1 µl, 3 µl and 5 µl of the diluted lentivirus stock to separate wells.

NOTE: To obtain an accurate titer, it is desirable to have less than 20% GFP positive cells at 72 hours post-transduction. This minimizes counting cells with multiple integration events, which would result in underestimation of titers.



Divide cultured cells 18-24 hours before transduction to ensure active cell division at the time of transduction.

Representative image of $\geq 40\%$ confluent 293T/17 cells:



6. Incubate the remaining assay wells at 37°C in 5% CO₂ for 72 hours post-transduction.

C. Cell harvest and analysis

1. Gently wash cells with 1X PBS and immediately add 100 µl of trypsin to each well.
2. Incubate the plate at 37°C and closely monitor cell rounding and detachment.
3. After cells have rounded, add 400 µl of complete growth media to each well to inactivate the trypsin and resuspend the cells.
4. Transfer 100 µl of cell suspension from each well to separate wells in a non-treated 96-well plate (or similar culture vessel) that is compatible with your flow cytometer.
5. Add 150 µl of complete growth medium to each well to dilute the cells. This is required to obtain accurate flow cytometry results.

NOTE: The optimal volume added for dilution may vary depending on the flow cytometer.

6. Analyze for GFP expression by flow cytometry.
7. Calculate the functional titer of the lentivirus stock using the following equation:

$$\text{Titer (Transducing units/ml)} = \left[\frac{\text{Number of target cells (Count at time of transduction)} \times [\% \text{ GFP positive cells}/100]}{\text{(Volume of lentivirus stock in ml)}} \right]$$

SECTION IV: AAV Generation in Adherent HEK 293T Cell Cultures

The following procedure describes plasmid DNA transfections for AAV generation in adherent HEK 293T cell types in a 6-well plate format. The surface areas of other culture vessels are different, and transfections must be scaled accordingly. Appropriately increase or decrease the amounts of serum-free medium, *TransIT-VirusGEN® SELECT* Reagent, total plasmid DNA and complete culture medium based on the size of the cell culture vessel (refer to **Table 3** below).

Table 3. Recommended *TransIT-VirusGEN® SELECT* starting conditions for AAV production

Culture vessel	6-well plate	10-cm dish	T75 flask	T175 flask	Corning® 2-STACK	Corning® 5-STACK
Surface area	9.6 cm ²	59 cm ²	75 cm ²	175 cm ²	1272 cm ²	3180 cm ²
Complete growth medium	2.0 ml	10 ml	15 ml	35 ml	260 ml	650 ml
PBS or Serum-free medium	200 µl	1.0 ml	1.5 ml	3.5 ml	26 ml	65 ml
AAV Plasmid DNA (Pre-mixed, 1 µg/µl stock)	3.0 µl	15 µl	22.5 µl	52.5 µl	390 µl	975 µl
<i>TransIT-VirusGEN® SELECT</i> Reagent	6 µl	30 µl	45 µl	105 µl	780 µl	1.95 ml



Surface areas are based on Falcon plates, dishes and flasks, and Corning CellSTACK® Culture Chambers. Volumes for cell growth and transfection complex formation are per culture vessel. For vessels not listed in this table, volumes of PBS, total DNA and *TransIT-VirusGEN® SELECT* Reagent can typically be scaled according to surface area (cm²).

Materials Required but Not Supplied

- HEK 293T cells (e.g. HEK 293T/17 cells, ATCC Cat. No. CRL-11268)
- Complete culture medium (e.g. DMEM + 10% FBS + 10 mM HEPES pH 7.4)
- Plasmid DNA (e.g. Agilent AAV2 pDNA: pAAV-hrGFP (Cat. No. 240074-51), pAAV-RC (Cat. No. 240071-53), pHelper (Cat. No. 240071-54))
- Phosphate Buffered Saline (PBS) (e.g. Millipore Sigma Cat. No. D8537)
- 10X Cell Lysis Buffer (500 mM Tris pH 8, 10% Tween® 20, 20 mM MgCl₂)
- 5 M Sodium Chloride (5 M NaCl)
- Benzonase® (e.g. Sigma Cat. No. E1014 or Syd Labs Cat. No. BP4200)




Divide cultured cells 18-24 hours before transfection to ensure active cell division at the time of transfection.

Transient Plasmid Transfection Protocol per Well of a 6-Well Plate

A. Plate cells

1. Approximately 18-24 hours before transfection, plate cells in 2.0 ml complete growth medium per well in a 6-well plate. A starting cell density of 4.0 - 5.0 × 10⁵ cells/ml is recommended. Cultures should be 80-95% confluent at the time of transfection (see representative image at right).
2. Incubate cell cultures at 37°C in 5% CO₂ overnight.

Representative image of ~80% confluent 293T/17 cells:



B. Prepare *TransIT-VirusGEN®*:DNA complexes (immediately before transfection)

1. Warm *TransIT-VirusGEN® SELECT* to room temperature and vortex gently before using.
2. Place 200 µl PBS in a sterile tube.
3. In a separate sterile tube, combine AAV plasmids per the manufacturer recommendations to a final concentration of 1 µg/µl (e.g. Combine Agilent AAV Helper-Free System plasmids at a 1:1:1 ratio as follows: 50 µg pAAV-hrGFP + 50 µg pAAV-RC + 50 µg pHelper in a total volume of 150 µl). Mix thoroughly.
4. Transfer 3.0 µl of the prepared DNA mixture into the tube containing PBS. Mix completely.
5. Add 6.0 µl *TransIT-VirusGEN® SELECT* Reagent to the diluted DNA mixture. Mix completely by inversion or vortexing. Do NOT agitate Reagent:DNA complexes again after this initial mixing.



Do NOT allow the *TransIT-VirusGEN® SELECT* Reagent to incubate alone in complex formation solution > 5 min, i.e. if the reagent is pre-diluted, add DNA within 5 min for optimal complex formation.

Do NOT agitate Reagent:DNA complexes after the initial mixing.

NOTE: This is a 2:1 mixture of transfection reagent to total DNA (vol:wt), which can be further optimized for AAV production using *TransIT-VirusGEN[®]* Reagent.

6. Incubate at room temperature for 15-60 minutes to allow transfection complexes to form.

C. Distribute the complexes to cells in complete growth medium

1. Add the *TransIT-VirusGEN[®]* SELECT Reagent:DNA complexes drop-wise to different areas of the wells.
2. Gently rock the culture vessel back-and-forth and from side-to-side to evenly distribute the *TransIT-VirusGEN[®]* SELECT Reagent:DNA complexes.
3. Incubate at 37°C in 5% CO₂ for 48-72 hours prior to AAV harvest. NOTE: It is not necessary to replace the complete growth medium with fresh medium post-transfection.

D. Harvest and storage of AAV

1. Following the 48-72 hour incubation, add 0.1X volume of 10X Cell Lysis Buffer (i.e. 0.2 ml) and 100 U/ml Benzonase[®] (i.e. 200 U) to each well. Incubate at 37°C for 1.5 hours with shaking.
2. Add 0.1X volume of 5 M NaCl (i.e. 0.2 ml) and mix completely. Incubate at 37°C for 30 minutes with shaking.
3. Transfer the entire cell lysate mixture to a sterile conical tube or appropriate vessel.
4. Centrifuge the mixture at 4,100 × g for 10 minutes to remove cell debris. Carefully transfer the AAV containing supernatant to a new sterile tube.
5. Store AAV stocks at -80°C.


Harvest of AAV with Freeze/thaw Procedure (Alternative)

1. Following the 48-72 hour incubation, scrape the cells from the plate using a cell scraper.
2. Transfer the total volume of cells and media (i.e. 2 ml) to a sterile conical tube or appropriate vessel.
3. To ensure sufficient lysis of the cells, freeze cells and media completely in a dry ice/ethanol bath. Visually inspect to verify that cells are frozen solid, then thaw in a 37°C water bath. Repeat freeze/thaw procedure a total of three times.
4. Add 100 U/ml Benzonase[®] (i.e. 200 U) to the cell lysate and mix gently but thoroughly. Incubate at room temperature for 30 minutes.
5. Centrifuge the cell lysate at 10,000 × g for 10 minutes to remove cell debris. Carefully transfer the AAV containing supernatant to a new sterile tube.
6. Store AAV stocks at -80°C.



Morphology changes in HEK 293T/17 cell following transfection with AAV plasmids are expected and indicate virus production.

Representative image of HEK 293T/17 cells 3 days post-transfection with pAAV-hrGFP, pAAV-RC and pHelper plasmids:



Benzonase[®] is a non-specific endonuclease used to liberate virus particles from residual nucleic acids in the cell lysates and increase AAV titers.

SECTION V: AAV Generation in Suspension HEK 293 Cell Cultures

The following procedure describes plasmid DNA transfections for AAV generation in 125 ml Erlenmeyer shake flasks using 25 ml of complete growth medium. If using an alternate cell culture vessel, increase or decrease the amounts of serum-free complex medium, *TransIT-VirusGEN®* SELECT Reagent and total DNA based on the **volume of complete growth medium** to be used. To calculate the required reagent quantities based on the recommended starting conditions and total culture volume, refer to the calculation worksheet in **Table 4** (below).

Table 4. Scaling worksheet for *TransIT-VirusGEN®* SELECT for AAV transfections

Starting conditions per milliliter of complete growth medium (AAV Generation)				
	Per 1 ml		Total culture volume	Reagent quantities
PBS or serum-free medium	0.1 ml	×	_____ ml	= _____ ml
Total Plasmid DNA (1 µg/µl stock)	2 µl	×	_____ ml	= _____ µl
<i>TransIT-VirusGEN®</i> SELECT Reagent	3 µl	×	_____ ml	= _____ µl

NOTE: Total Plasmid DNA refers to the combined weight of AAV plasmids (in µg) per transfection.

Materials Required but Not Supplied

- Suspension HEK 293 Cells (e.g. Expi293F™ Cells, Gibco Cat. No. A14527)
- Complete Culture Medium (e.g. Expi293F™ Expression Medium, Gibco Cat. No. A1435101)
- Plasmid DNA (e.g. Agilent AAV2 pDNA: pAAV-hrGFP (Cat. No. 240074-51), pAAV-RC (Cat. No. 240071-53), pHelper (Cat. No. 240071-54))
- Phosphate Buffered Saline (PBS) (e.g. Millipore Sigma Cat. No. D8537)
- Erlenmeyer shake flasks (e.g. Corning® Cat. No. 431143 or Thomson Cat. No. 931110)
- 10X Cell Lysis Buffer (500 mM Tris pH 8, 10% Tween® 20, 20 mM MgCl₂)
- 5 M Sodium Chloride (5 M NaCl)
- Benzonase® (e.g. Sigma Cat. No. E1014 or Syd Labs Cat. No. BP4200)

Transient Plasmid Transfection Protocol per 25 ml HEK 293 Culture

A. Maintenance of cells

1. Passage suspension HEK 293 cells 18-24 hours prior to transfection to ensure that cells are actively dividing at the time of transfection and to obtain a density of 2 - 3 × 10⁶ cells/ml the next day.

NOTE: Perform cell counts and evaluate viability daily to ensure that cells are doubling every 24 hours and ≥ 95% viable by trypan blue exclusion. DO NOT proceed with transfection if cells are not doubling normally or are < 95% viable.

2. Incubate cells overnight at appropriate temperature and CO₂ levels (e.g. 37°C, 5-8% CO₂, shaking).

B. Prepare *TransIT-VirusGEN®*:DNA complexes (immediately before transfection)

1. Immediately prior to transfection, seed cells at a density of 2 × 10⁶ cells/ml into a transfection culture vessel (e.g. 25 ml per 125 ml Erlenmeyer shake flask).
2. Warm *TransIT-VirusGEN®* SELECT to room temperature and vortex gently before using.
3. Place 2.5 ml of PBS in a sterile tube.
4. In a separate sterile tube, combine AAV plasmids per manufacturer recommendations to a



Divide cultured cells 18-24 hours before transfection to ensure that cells are actively dividing at the time of transfection.

final concentration of 1 µg/µl (e.g. Combine Agilent AAV Helper-Free System plasmids at a 1:1:1 ratio as follows: 50 µg pAAV-hrGFP + 50 µg pAAV-RC + 50 µg pHelper in a total volume of 150 µl). Mix thoroughly.

- Transfer 50 µl of the DNA mixture prepared in Step B.4 to the tube containing PBS. Mix completely.
- Add 75 µl TransIT-VirusGEN® SELECT Reagent to the diluted DNA. Mix completely by inversion or vortexing. Do NOT agitate Reagent:DNA complexes again after this initial mixing.

NOTE: This is a 1.5:1 mixture of transfection reagent to total DNA (vol:wt), which can be further optimized for AAV production using TransIT-VirusGEN® SELECT Reagent.

- Incubate at room temperature for 15-60 minutes to allow transfection complexes to form.

C. Distribute the complexes to cells in complete growth medium

- Add the TransIT-VirusGEN®:DNA complexes (prepared in Step B) to culture vessel.
- Shake flasks on an orbital shaker (125 rpm when using a shaker with a 1.9 cm orbital throw) at appropriate temperature and CO₂ levels (e.g. 37°C, 5-8% CO₂).
- Incubate cultures for 48-72 hours prior to AAV harvest.

D. Harvest and storage of AAV

- Following the 48-72 hour incubation, transfer the total volume of cell suspension (i.e. 27.5 ml) to a sterile conical tube or appropriate vessel.
NOTE: See 'Freeze/thaw Procedure' below for an alternative method to harvest AAV.
- Add 0.1X volume of 10X Cell Lysis Buffer (i.e. 2.75 ml) and 100 U/ml Benzonase® (i.e. 2,750 U). Mix completely and incubate at 37°C for 1.5 hours with shaking.
- Add 0.1X volume of 5 M NaCl (i.e. 2.75 ml) and mix completely. Incubate at 37°C for 30 minutes with shaking.
- Centrifuge the mixture at 4,100 × g for 10 minutes to remove cell debris. Carefully transfer the AAV containing supernatant to a new sterile tube.
- Store AAV stocks at -80°C.

Harvest of AAV with Freeze/thaw Procedure (Alternative)

- Prepare a dry ice/ethanol bath.
- Centrifuge cell suspension at 1,750 × g for 10 minutes.
- Remove the supernatant and process as needed.
- Add 5.5 ml of Freeze/Thaw Lysis Buffer (50 mM Tris pH 8.5, 150 mM NaCl, 2 mM MgCl₂) to the cell pellet. Mix thoroughly until cell clumps are no longer visible. NOTE: The required volume of Freeze/Thaw Lysis Buffer is calculated by multiplying the transfected cell culture volume by 0.2 ml.
- To ensure sufficient lysis of the cells, freeze cells completely in the dry ice/ethanol bath. Visually inspect to verify that cells are frozen solid, then thaw in a 37°C water bath. Repeat freeze/thaw procedure a total of three times.
- Add 50 U/ml Benzonase® (i.e. 275 U) to the cell lysate and mix gently but thoroughly. Incubate at room temperature for 30 minutes.
- Centrifuge the cell lysate at 10,000 × g for 10 minutes to remove cell debris. Carefully transfer the AAV containing supernatant to a new sterile tube.
- Store AAV stocks at -80°C.



Do NOT allow the TransIT-VirusGEN® SELECT Reagent to incubate alone in complex formation solution > 5 min, i.e. if the reagent is pre-diluted, add DNA within 5 min for optimal complex formation.

Do NOT agitate Reagent:DNA complexes after the initial mixing.



There is no need to change culture medium after transfection, unless required by your cell type or culture conditions.

SECTION VI: AAV Transduction/Titering Method Using a GFP Reporter Virus

The following procedure describes transduction of HT-1080 cells grown in a 24-well format with a GFP reporter AAV2 and is meant to determine functional AAV2 titers. The number of wells needed for this assay will depend on the number of AAV stocks titered and the number of dilutions required for testing per stock (see step B.3). Testing several dilutions is recommended to accurately determine the functional AAV2 titer. This protocol can be adapted to transduce cells that are permissive to different AAV serotypes.

Materials Required, but Not Supplied

- HT-1080 cells (ATCC Cat. No. CCL-121)
- Dulbecco's Modified Eagle Medium (DMEM) (Corning Cat. No. 10-013-CV)
- Complete HT-1080 cell culture medium (e.g. DMEM + 10% FBS)
- DMEM + 2% FBS for AAV dilutions
- AAV stock(s) expressing GFP reporter
- 24-well tissue culture plate(s)
- 1X PBS and trypsin
- Flow cytometer equipped with a GFP compatible laser

A. Plate cells

1. Approximately 4-6 hours before transduction, plate HT-1080 cells in 0.5 ml complete growth medium per well in a 24-well plate. A starting cell density of 1×10^5 cells/ml is recommended. Cells should be adhered to the plate and 40-50% confluent at the time of transduction.
2. Record the cell count, which is critical to determine an accurate functional titer.

B. Transduce with GFP-encoding recombinant AAV

1. Thaw AAV stock(s) in 37°C water bath. Remove promptly after virus has thawed to prevent virus inactivation. Gently mix virus stock.
2. Make 1:250 and 1:1000 dilutions of the AAV stock(s) in DMEM + 2% FBS.
NOTE: Each test well will receive 50 µl of the appropriate dilution. Lower or higher dilutions may be required depending on the serotype and AAV production conditions.
3. Add 50 µl of the appropriate AAV dilution to wells containing cells.
4. Incubate the assay wells at 37°C in 5% CO₂ for 48 hours post-transduction.
NOTE: To obtain an accurate titer, it is desirable to have less than 20% GFP positive cells at 48 hours post-transduction. This minimizes counting cells with multiple integration events, which would result in an underestimation of titer.


C. Cell harvest and analysis

1. Gently wash cells with 200 µl 1X PBS. Following the removal of PBS, immediately add 100 µl of trypsin to each well.
2. Incubate the plate at 37°C and closely monitor cell rounding and detachment.
3. After cells have rounded, add 400 µl of complete growth media (e.g. DMEM + 10% FBS) to each well to inactivate the trypsin and resuspend the cells. NOTE: The cells should be at $\sim 1 \times 10^6$ cells/ml. The cells can be further diluted in growth media if desired.
4. Transfer 250 µl of cell suspension from each well to separate wells in a non-treated 96-well plate (or similar culture vessel) that is compatible with your flow cytometer.
NOTE: The optimal volume added for dilution may vary depending on the flow cytometer.



Cells can also be plated 18-24 hours before transduction, but at a lower density (7.5×10^4 cells/ml) to ensure 40-50% confluency at the time of transduction. If plated the day before, the cells should be trypsinized and counted again at the time of transduction because cells will likely have divided and increased in number.

Representative image of ~50% confluent HT-1080 cells:





5. Analyze for GFP expression by flow cytometry.
6. Calculate the functional titer of the AAV stock using the following equation:

$$\text{Titer (HT-1080 Transducing units/ml)} = \left[\frac{\text{Number of target cells (Count at time of transduction)} \times [\% \text{ GFP positive cells}/100]}{\text{(Volume of AAV Stock in ml)}} \right]$$

NOTE: To determine the functional titer produced per milliliter of total culture, multiply the AAV stock titers determined above by the dilution factor at harvest (e.g. for AAV produced in HEK 293 cultures and harvested as described in Section IV.D and V.D, multiply AAV stock titers determined above by 1.2).

TROUBLESHOOTING GUIDE

POOR DNA TRANSFECTION EFFICIENCY	
Problem	Solution
Incorrect vector sequence	If you do not observe expression of your target insert, verify the sequence of the transfer vector plasmid DNA.
Suboptimal <i>TransIT</i> ® Reagent:DNA ratio	Determine the best <i>TransIT</i> -VirusGEN® SELECT Reagent:DNA ratio for each cell type. Titrate the <i>TransIT</i> -VirusGEN® SELECT Reagent volume from 2-4 µl (lentivirus) or 1-3 µl (AAV) per 1 µg DNA. Refer to “Before You Start” on Page 2 for recommended starting conditions.
Suboptimal DNA concentration	Determine the DNA concentration accurately. Use plasmid DNA preps that have an A _{260/280} absorbance ratio of 1.8-2.0. The optimal DNA concentration generally ranges between 0.5-2 µg per 1 ml of culture. For lentivirus, start with 1 µg DNA per 1 ml of culture. For AAV, start with 2 µg DNA per 1 ml of culture. Consider testing different amounts of DNA while scaling the amount of <i>TransIT</i> -VirusGEN® SELECT accordingly.
Low-quality plasmid DNA	Use highly purified, sterile, endotoxin- and contaminant-free DNA for transfection. We recommend using Mirus MiraCLEAN® Endotoxin Removal Kit (MIR 5900) for removal of endotoxin from your DNA preparation. Alternatively, use cesium chloride gradient or anion exchange purified DNA which contains levels of endotoxin that do not harm most cells. Do not use DNA prepared using miniprep kits as it might contain high levels of endotoxin.
Cells not actively dividing at the time of transfection	Divide the culture at least 18-24 hours before transfection to ensure that the cells are actively dividing and reach optimal cell density at time of transfection. DO NOT proceed with transfection if cells are not doubling normally or are < 95% viable by trypan blue exclusion.
Transfection incubation time not optimal	Determine the optimal transfection incubation time for each cell type and experiment. Test a range of incubation times (e.g. 48-72 hours). The best post-transfection incubation time for lentivirus production is typically 48 hours; the best post-transfection incubation time for AAV is typically 48-72 hours.
<i>TransIT</i> -VirusGEN® SELECT was not mixed properly	Warm <i>TransIT</i> -VirusGEN® SELECT Reagent to room temperature and vortex gently before each use. If <i>TransIT</i> -VirusGEN® SELECT Reagent is pre-diluted in complex formation solution, DNA should be added within 5 min. Incubating the <i>TransIT</i> -VirusGEN® SELECT Reagent in complex formation solution alone for an extended time results in reduced production of functional virus.
Disruption of transfection complex formation	After initial mixing of DNA and <i>TransIT</i> -VirusGEN® SELECT Reagent, do not agitate Reagent:DNA complexes again, e.g. do not vortex or invert before adding to cultures.
Precipitate formation during transfection complex formation	During complex formation, scale all reagents according to the scaling tables provided in each section of the protocol, including: serum-free media, <i>TransIT</i> -VirusGEN® SELECT and plasmid DNA. Precipitation may be observed when excess DNA is used during complex formation. This may negatively impact transfection efficiency. To avoid precipitation when using high concentrations of DNA, increase the volume of serum-free medium during complex formation by two-fold.
Proper experimental controls were not included	To assess delivery efficiency of plasmid DNA, use Mirus <i>Label IT</i> ® Tracker™ Intracellular Nucleic Acid Localization Kit to label the target plasmid or use Mirus pre-labeled <i>Label IT</i> ® Plasmid Delivery Controls (please refer to Related Products on Page 16). To verify efficient transfection, use <i>TransIT</i> -VirusGEN® SELECT Reagent to deliver a positive control such as a luciferase, beta-galactosidase or green fluorescent protein (GFP) encoding plasmid.

TROUBLESHOOTING GUIDE continued

HIGH CELLULAR TOXICITY	
Problem	Solution
Cell density not optimal at time of transfection	High toxicity and cell death may be observed if cells are less than 80% confluent at the time of transfection. For high virus titers using <i>TransIT-VirusGEN® SELECT</i> Reagent, ensure that cell cultures are between 80 and 95% confluent (for adherent cell transfections) or approximately $2-3 \times 10^6$ cells/ml (for suspension cell transfections) at the time of transfection.
Cell morphology has changed	When generating lentivirus, overexpression of the vesicular stomatitis virus (VSV) G protein causes changes in cell morphology and can even result in cell-cell fusion. This is normal and does not adversely affect virus titers.
	Mycoplasma contamination can alter cell morphology and affect transfection efficiency. Check your cells for mycoplasma contamination. Use a fresh frozen stock of cells or use appropriate antibiotics to eliminate mycoplasma.
	A high or low cell passage number can make cells more sensitive and refractory to transfection. Maintain adherent or suspension HEK 293 cells below passage 30 for optimal recombinant virus production.
Transfection complexes not evenly distributed after complex addition to cells	Add transfection complexes drop-wise to the cells. Gently rock the dish back-and-forth and from side-to-side to distribute the complexes evenly. Do not swirl or rotate the dish, as this may cause uneven distribution.
Transfection complexes added to adherent cells cultured in serum-free medium	<i>TransIT-VirusGEN® SELECT</i> Transfection Reagent efficiently transfects cells cultured in serum-free medium; however, toxicity may be higher if serum is not present when transfecting adherent cells typically cultured in serum-containing complete media. If toxicity is a problem, consider adding serum to the culture medium.

RELATED PRODUCTS

- *TransIT*-VirusGEN[®] GMP Transfection Reagent
- *TransIT*-VirusGEN[®] Transfection Reagent
- VirusGEN[®] AAV Transfection Kit
- VirusGEN[®] LV Transfection Kit
- VirusGEN[®] SELECT AAV Transfection Kit
- VirusGEN[®] SELECT LV Transfection Kit
- VirusGEN[®] GMP AAV Transfection Kit
- VirusGEN[®] GMP LV Transfection Kit
- *TransduceIT*[™] Reagent
- *Label IT*[®] Plasmid Delivery Controls
- *Label IT*[®] Tracker[™] Intracellular Nucleic Acid Localization Kits
- MiraCLEAN[®] Endotoxin Removal Kits
- *TransIT*[®]-Lenti Transfection Reagent

For details on the above-mentioned products, visit www.mirusbio.com



Reagent Agent[®]

Reagent Agent[®] is an online tool designed to help determine the best solution for nucleic acid delivery based on in-house data, customer feedback and citations.

Learn more at:
www.mirusbio.com/ra